


TO CHANGE COLORS
JUST CHANGE CARTRIDGES

If your pen is writing blue-black and you wish to write in red (or other color) simply change to a red cartridge—in 15 seconds! Change back when you again wish to write blue-black.



**READ
CAREFULLY
BEFORE
RELOADING**

EVERSHARP CA

**READ CAREFULLY
BEFORE RELOADING**

WARNING

INSTRUCTIONS

SERVICE GUARANTEED FOREVER. If your EVERSHARP ever needs service we will put it in good order for 35¢. This service is guaranteed not for years, not for life, but **GUARANTEED FOREVER.**

EVERSHARP CA

RELOAD CARTRIDGE

PRICE 50¢

Available in blue-black, red, green, violet.

Available at stores everywhere in your choice of four colors. To write in a different color simply replace with the reload cartridge of different color.

DO NOT BREAK OPEN UNTIL READY TO USE

YOUR *EVERSHARP CA* WORKS BEST ONLY WHEN YOU FOLLOW THESE INSTRUCTIONS



HOLD POINT DOWN
1. Unscrew pen barrel from pen tip at gold ring by turning right to left.



RED END DOWN
3. Hold new cartridge between thumb and index finger below perforated line, red end pointing downwards.




HOLD POINT DOWN
5. While holding cartridge vertically, remove the entire paper label.




HOLD POINT DOWN
7. With cartridge nozzle still pointing down, screw (left to right) into pen tip until tight. DO NOT TIGHTEN TOO MUCH!



HOLD POINT DOWN
2. Remove empty cartridge from pen tip by turning cartridge right to left.



RED END DOWN
4. With other hand, unscrew cartridge from cap. Be sure to hold in vertical position.



HOLD POINT DOWN
6. Tap cartridge nozzle gently on pad of paper until solid drop of ink appears.



HOLD POINT DOWN
8. Replace pen barrel. Tighten left to right. Write a few lines to start ink flow through Magic Sphere.

WHEN PEN STOPS WRITING YOU NEED A NEW CARTRIDGE

Cartridges are available at all good pen counters. Buy the color you want and follow instructions in package.

You can tell if a cartridge is empty by tapping nozzle gently on a pad of paper. If drop of ink appears, cartridge still contains ink.

DO NOT REMOVE CARTRIDGE UNNECESSARILY.